

Multi Layer Installation

Recommended saws for cutting/trimming

Slower speed blades cut rubber best. Bandsaw, jigsaw, handsaw, utility knife.

Avoid using skill saw, table saw



1

Prepare base

2

Place stackwall piece and ensure level. Bend for desired look.



3

Drill pilot hole for ground stake



4

Pound 12" ground stake through rubber into the ground.



5

Screw 2 1/2" deck screws from back to secure layered blocks.

